



ETF WEST LLC
Division of Energy Task Force LLC

Pre-insulated pipe

7700 W Olive Ave - Peoria, AZ - 85345 - 623-878-4377 - 623-878-6683

Field installation instruction for 90° kit with PVC jacket
Prior to installing fittings slide all fitting covers over pipe



With fitting installed slide sleeve



**into position
on pipe**



Apply tapecoat to all seams



Drill 1" hole on each side for foam



on each side of fitting



Pour foam in the 1" hole



Apply tapecoat over 1" hole



Finished 90°