

7700 W Olive Ave - Peoria, AZ - 85345 - 623-878-4377 - 623-878-6683

Field installation instruction for 45° kit with PVC jacket Prior to installing fittings slide all fitting covers over pipe



With fitting installed slide sleeve

into position on pipe

Apply tapecoat to all seams



Drill 1" hole on each side for foam



on each side of fitting



Pour foam in the 1" hole



Apply tapecoat over 1" hole



Finished 45°