



ETF WEST LLC
Division of Energy Task Force LLC

Pre-insulated pipe

7700 W Olive Ave - Peoria, AZ - 85345 - 623-878-4377 - 623-878-6683

Field installation instruction for field joint kit with PVC jacket Prior to connecting pipe slide all fitting covers over pipe



With pipe connected installed slide sleeve



into position on pipe



Apply tapecoat to all seams



Drill 1" hole on each side for foam



on each side of sleeve



Pour foam in the 1" hole



Apply tapecoat over 1" hole



Finished Joint