



ETF WEST LLC
Division of Energy Task Force LLC

Pre-insulated pipe

7700 W Olive Ave - Peoria, AZ - 85345 - 623-878-4377 - 623-878-6683

Field installation instruction for Tee kit with PVC jacket
Prior to installing fittings slide all fitting covers over pipe



Once Tee is assembled



Install pre-drilled sleeve on pipe



Sleeve in place



Drill 1" hole on each side for foam and apply tapecoat to seams



Slide branch sleeve into position



Drill 1" hole on each side for foam and apply tapecoat to seams



Pour foam in the 1" hole



Finished Tee