



Energy Task Force

Pre-insulated Pipe

2475 Clark St • Apopka, FL 32703 • 407-523-3770 • 407-523-3722

Field installation instruction for joint kit with HDPE jacket



Measure sleeve length and mark jacket on both sides



Cut jacket to expose foam (approx. 3") on both ends of joint

Install HDPE sleeve



Tape sleeve to hold and seal for foam

Drill 1" hole on each end of joint



Mix equal parts of A & B and pour in joint. Remove tape and apply heat shrink to all seams